



HIGH-END NMEA CONNECT PLUS GATEWAY







0. Index

1. Brief description of product and layout.

- 1.1 Brief description of product.
- 1.2 NCP High-End layout.

2. Use cases

- 2.1 How to display wind data from the NCP High-End via Wifi on PC Display from the Calypso Instruments Portable and Wired Ranges.
- 22 How to display wind data from the NCP High-End via Bluetooth or Wifi on Anemotracker App from the Calypso Instruments Portable and Wired Ranges.
- 2.3 How to display wind data from the NCP High-End via NMEA 2000 cable on a Raymarine display from the Calypso Instruments Portable and wired Ranges.
- 2.4 How to display wind data from the NCP High-End via NMEA 2000 cable on a B&B display from the Calypso Instruments Portable and Wired Ranges.
- 2.5 How to display data from the NCP High-End via NMEA 2000 cable on a Humminbird display from the Calypso Instruments Portable and Wired Ranges.




1. Brief description of product and layout

1.1 Brief description

The NMEA Connect Plus High-End (NCP- High End), can be connected to the Calypso Instruments Portable Range via Bluetooth Low Energy (BLE) and also to the Calypso Instruments Wired Range. The NCP High-End can also be forward connected to both NMEA 0183 and NMEA 2000 chartplotters, displays or NMEA backbones.


The diagram below outline the connection pathway:

Calypso Instruments Portable Range.




ULTRASONIC PORTABLE SOLAR

Calypso Instruments Wired Range.





- 1. Brief description of product and layout
- 1.1 NCP High-End layout.



Main terminal pins:

- PORT 2: 2. GND, 2 485+, 2 485-
- INPUT POWER : GND, + 12V
- PORT 1: 1.GND ,1 485+,1 485-
- USB: +5V, D+, D-, GND
- NMEA 2000 : GND, CAN L, CAN H, 12V

The NCP High-End is labeled with:

- MAC: Unique identifier number
- SSID : NCP wifi name
- PASSWORD : Password for Wifi connection
- IP: IP Address
- DB ADDRESS : Bluetooth direction address
- 0183 WIFI SERVER PORT:0183 Wifi server port as per default
- MOD: NMEA Connect Plus High-End model.

MODEL: HIGH_END MAC: B8:F0:09:92:16:B1 SSID: Nmea+B8:F0:09:92:16:B1 PASSWORD: 4fbfa71a08af IP: 192.168.4.1 BLE: B8:F0:09:92:16:B2 N0183 WIFI PORT: 50000



4.1 How to display data from the NCP High-End via Wifi on PC Display from the Calypso Instruments Portable and Wired Ranges.

For those who are looking for displaying wind data on a second device.

To carry our this connection you will need to use a chart plotter. For this user case, we have used OPENCPN.

- Download OPENCPN or any other chart plot and run it.
- Open the OPENCPN and cick on *options*.
- Once in options, click on *connections* , and *scroll* down the menu find the Add connection button. Click on *Add connection.*

Options			1			×
Display	Charts	Consections	I Ships	User Inter		ins
General Trans NMEA Cox	ine and Speo	t data . Filter peri-	or bed ()			0
Show INIEA Det Format uploads t Lize Garmin GRM Use magnetic be	for Turuno GP IN (Hittit) mor	le for coloads				
Data Corectium						- 1
Add Connection	Roma Pd	-				
Imput fatoring						*
				OK .	Cancer	Apply


• Once in Add connection, click on **Network** and **TCP**.

Options	×
Diplay Charts Co	exection. Ships User Interface Plages
	1.1
Configure new connection	
Oserial #Network Protocol	
Addmin	182,162,4.1
DataRot	50000
User Comment.	
Munity 1 -	
Control checksum	
Cleaning in section with Bart Class	tpat an this port (as subspike) or NMEA repeater)
be present when on my upp. (1) (on	
21 Streets control 2 month	
Terrer Scherner Lander Group	
nne States Cariser & K. Affrederingen V	



4.1 How to display data from the NCP High-End via Wifi on PC Display from the Calypso Instruments Portable and Wired Ranges (continuation).

- Type 192.168.4.1 in address field, which is the Ip address that you will find on the NCP High-End label.
- Input 50000 in the data port field. This is the wifi server port that you will find on your NCP High-End's label. If for any reason you have updated this number, input it in this field.
- Click on Apply.



- In the next screen, make sure that the *Enable* checkbox is selected.
- Click Ok.

Dations						×
Ungliny	Outs.	econection.	anips	User Interface	Pages	
General Hitter NMBA	Course and Spee	el data : Filter perio	x 580 1			•
Use Garmin G	ds for Funancial RMN (Host) mo		-	1		
Data Connection						
Stub	e Type Network Comment	Input TCP		dress Network Port 4.1 50000	Priority	
¢					- 9	
Add Connector	e1					
Inc.d Ellering						
Output Shering						
			5	Dit Canor	App	y




4.1 How to display data from the NCP High-End via Wifi on PC Display from the Calypso Instruments Portable and Wired Ranges (continuation).

• Make sure you are connected to the NCP High-End in order to see wind data. There are two ways to see displayed data on OPENCPN :

From connections- Show NMEA debug window.

Same Contraction of the Contract	K1 tetelitik Derivan Window	×
Consistion Constitution Constenee Constenee Constitution Constitution Constitut	11.1.4.5.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA SHA TA 1 - HOT - HOL - HOL - 11.2.4.6.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA SHA TA 1 - HOT - HOL - 11.2.4.6.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - 11.2.4.6.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - 11.2.4.6.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 1 - HOL - 11.2.5.6.1 (ToP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HeL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 11.2.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 12.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 12.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C JANA C - HOT - HOL 0 - 12.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C - HOT - HOL 0 - HOL 0 - 12.5 (HEL 1 TOP 10.5 (HEL 1 SHOODS SHOW C JANA C - HOL 0 - HOL 0 -	
Share Nor Director Protocy Artech Addies Testeck Rol Picety Network Input 100° 102.188.4.1 5000 1 Cannese	Tran -	
	Verse super	at 1
Add Convector	Text and any Mark and Angel (angel) Next Nextge (Next and Angel) Outs Nextge (Nextge of Next angel)	STV .
head filming		
Output themp		
CR Cancer August		

From the dashboard.





NMEA Connect Plus High-End User manual


4.2 How to display data from the NCP High-End via Bluetooth or Wifi on Anemotracker App from the Calypso Instruments Portable and Wired Ranges.

For those who are looking for displaying wind data on a second device. To carry out this connection you will need to use Anemotracker App, available for iOS and Android users.

You can visualize data from the NCP High-End via Bluetooth or via Wifi.

Visualization via Bluetooth


- Go to Anemotracker app from your mobile or tablet devices.
- In the main menu, press on *Pair Portable*.





4.2 How to display data from the NCP High-End via Bluetooth or Wifi on Anemotracker App from the Calypso Instruments Portable and Wired Ranges (continuation).

• in the available devices to pair, pair to the one called ULTRA NCP. That is your NCP. Press on that one to connect the unit.



• Start receiving data in Anemotracker app.



4.2 How to display data from the NCP High-End via Bluetooth or Wifi on Anemotracker App from the Calypso Instruments Portable and Wired Ranges (continuation).

Visualization via WIFI (continuation)

- Connect the NCP to a power supply.
- From your computer, click on wi-fi and select the NMEA wifi network (it will always be named as NMEA+ a number and you can find it on your NCP-High-end label.).
- Type the wifi address that you will find on the NCP High-end label.
- Click on connect.
- Once connected, go to Anemotracker app, in your mobile or tablet devices.
- In the main menu, press on **Pair NCP**.





4.2 How to display data from the NCP High-End via Bluetooth or Wifi on Anemotracker App from the Calypso Instruments Portable and Wired Ranges (continuation).

Visualization via WIFI (continuation)

- In the Server address field, type 192.168.4.1. on ip address . You will find it on the NCP High-End's label.
- In the server port field, type 50000. This is the wifi server port that you will find on your NCP High-End's label. If , for any reason, you have updated this number, input it in this field.

lur-	CALV	PSO	(2)
C.C.	Server Addre	:55	
	192.168.4.1		
100	Server Port		
-	50000		
ali i			
h			
W			
Da Ba			
- 14			
i.		Connect	Cancel
	Prives	y Policy	
	<	0	Ш


• Start receiving data in Anemotracker app.




4.2 How to display data from the NCP High-End via NMEA 2000 cable on the Raymarine display from the Calypso Instruments Portable and Wired Ranges.

For those who are looking for displaying wind data on a second device. To carry out this connection you need to use a Raymarine display. In this case, we are using an **AXIOM 9 RV** Raymarine display.

• Once in the Raymarine dashboard, press on Settings.



Once in settings, press on **Network.** Make sure your NCP High-End appears in this section as it means it is connected. If for some reason you don't see it, it means the NCP High-End is not being detected by the Raymarine display. Please double check your connection. If the issue persists, contact us at **sales@calypsoinstruments.com**.





4.2 How to display data from the NCP High-End via NMEA 2000 cable on the Raymarine display from the Calypso Instruments Portable and Wired Ranges.

• Go back to Dasboard. Start reading wind data.



If ,for some reason, you don't see a zero data in your dashboard, it means that the NCP High-End is connected but it is not receiving data from the wind meter. In this case, please double check the wind meters' connection. If you see nothing (please see picture below), it means the NCP High-End is not well connected. Please, double check the connection. If the issue persists please contact us at *sales@calypsoinstruments.com*.





4.2 How to display data from the NCP High-End via NMEA 2000 cable on the B&G display from the Calypso Instruments Portable and Wired Ranges.

For those who are looking for displaying wind data on a second device. To carry out this connection you need to use a B&G display. In this case, we are using a **TRITON 2** B&G display.

• Once in the B&G dashboard, press on **Settings.** Scroll down and select **System**.

	B&G	
	Settings	
	💷 Remote displays 🛛 💡	
	Calibration	and the second
	ED Damping	and the second second
	🖽 Trip log 🔹 🔸	
4	🔺 Alarms 🔹 🕨	
	<u> 4 AIS</u>	The second division in which the
	System •	
		Contraction of the local division of the loc
	· · · · · · · · · · · · · · · · · · ·	

Once in system, select Network.





•

4.2 How to display data from the NCP High-End via NMEA 2000 cable on the B&G display from the Calypso Instruments Portable and Wired Ranges.

• In network, select Sources.



In sources, click on Auto Select.





•

4.2 How to display data from the NCP High-End via NMEA 2000 cable on the B&G display from the Calypso Instruments Portable and Wired Ranges.

• Once in autoselect, press on **Start**.



A progress bar will be shown to let you know it is looking for devices connected to the NMEA 2000 network. In this picture below, the B&G is recognizing the NCP High-End. If you B&B display does not recognize your NCP High-End please double check the connection. If the issue persists, contact us at *sales@calypsoinstruments.com.*





4.2 How to display data from the NCP High-End via NMEA 2000 cable on the B&G display from the Calypso Instruments Portable and Wired Ranges.

• As soon as the search is completed, press on *Close*.



Go back to **Dashboard.** Start receiving wind data. If you don't receive data please double check the connection. If the issue persists, please contact us at **sales@calypsoinstruments.com**





4.2 How to display data from the NCP High-End via NMEA 2000 cable on the Humminbird display from the Calypso Instruments Portable and Wired Ranges.

For those who are looking for displaying wind data on a second device. To carry out this connection you need to use a Humminbird display. In this case, we are using a **SOLIX 10MDI G2 CHO** Humminbird display.

• Once in the Humminbird dashboard, press on **Settings.**



Once in settings, go to **Network** and select **Data Sources.**

Settings	Network	â X	
CHIRP Soner	System Info		ø
Chart	Network Info		ø
Nevigation	Configure New Network		c
General		Source Settings	î
My Vessel	Data Sources		=
Network		Sensor Port	
Simulation	Speed Sensor		=
Restore Defaults	Temp Sensor		=
	NMEA 0183 (1)		E
	NMEA 0183 (2)		=
	NMEA 2000		=



4.2 How to display data from the NCP High-End via NMEA 2000 cable on the Humminbird display from the Calypso Instruments Portable and Wired Ranges.

• One in data sources, press on *Wind Speed & Direction*.

Settings	Data Sources	6.9	ŵ	x	
CHIRP Sonar	Pitch and Roll				=
Chart	AIS				=
Nevigation		Temperat	ure		
General	Temp (1)				=
My Vessel	Temp (2)				Ξ
Network	Temp (3)				3
Simulation	Temp (4)				=
Restore Defaults	-	Environment	al Data		iii
	Wind Speed and Direction				2 1
	Air Temperature				E
	Barometric Pressure				=
	Wind Chill and Heat Index				1

Make sure the NCP High-End shows up there. Select the NCP High-End to make sure your NCP High-End wireless recognizes your NCP High-End. If it doesn't, please double check your connection. If the issue persists, contact us at *sales@calypsoinstruments.com*.

Home	Wind Speed and Direction	C7	ŵ	x	
CHIRP Soner	Select the source for Wind Speed and Directo	•			
Chart	Auto-Configure				
Navigation	This Unit:	SOLIX 10 MDH	62 - 18111	5020164	
General	None				0
My Vessel	NMEA 2000: NMEA CONNECT PLUS (NdewoodSieliski			۲
Network					
Simulation					
Restore Defaults					



4.2 How to display data from the NCP High-End via NMEA 2000 cable on the Humminbird display from the Calypso Instruments Portable and Wired Ranges.

• Go back to dashboard. Start receiving wind data.





